

RMTF-170-3G-TT RMTF-170-3G-RM

17.3" Audio/Video Tabletop/Rack Mount Monitors User Guide

User Guide

Part Number 821824, Revision A

© 2018 Wohler Technologies, Inc. All rights reserved.

This publication is protected by federal copyright law. No part of this publication may be copied or distributed, stored in a retrieval system, or translated into any human or computer language in any form or by any means electronic, mechanical, manual, magnetic, or otherwise, or disclosed to third parties without the express written permission of Wohler Technologies.

Reproduction

Licensed users and authorized distributors of Wohler Technologies, Inc. products may copy this document for use with Wohler Technologies., Inc. products provided that the copyright notice above is included in all reproductions.

Customer Support

Wohler Technologies, Inc. 31055 Huntwood Avenue Hayward, CA 94544 www.wohler.com Phone: 510-870-0810 FAX: 510-870-0811 US Toll Free: 1-888-596-4537 (1-888-5-WOHLER) Web: www.wohler.com Sales: sales@wohler.com Support: support@wohler.com

Disclaimers

Even though Wohler Technologies, Inc. has tested its equipment and software, and reviewed the documentation, Wohler Technologies, Inc. makes no warranty or representation, either express or implied, with respect to software, documentation, their quality, performance, merchantability, or fitness for a particular purpose.

In no event will Wohler Technologies, Inc. be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect in the hardware, software, or its documentation, even if advised of the possibility of such damages.

Some states do not allow the exclusion or limitation for incidental or consequential damages, so the above exclusion or limitation may not apply to you.

Printing

This document looks best when printed on a color printer since some images may be indistinct when printed on a black and white printer.

PDF

All text strings underlined in this shade of blue are hyperlinks within this document.

Last Update

July 23, 2018

TABLE OF CONTENTS

Contents

User Guide	1
TABLE OF CONTENTS	3
Contents	3
CHAPTER 1: Installation	4
Introduction	4
Overview Features	4 4
Safety	4
Instructions	4 5
Mounting	5
Heat Dissipation Sympathetic Vibration	6 6
Mechanical	6
Electrical Interference	6
Power	6
	/
ICES-003	7
CHAPTER 2: Local Operation	8
Front Panel	8
On-Screen Display Features	9
Rear Panel	11
Rear Panel Connectors	13
Front Panel Menu Operation	13
Input Quick Menu OSD Menus	13 14
OSD Menus	15
CHAPTER 3. Technical Info	25
Supported Video Formate	<u>د م</u> . مد
Supported video Formats	20

Introduction

Overview

The RMTF-170-3G-TT and RMTF-170-3G-RM monitors set a new standard in LCD monitors for broadcast and professional video applications. They provide a 17.3", 10-bit, 1920 x 1080 resolution, 16:9 format, anti-glare IPS LCD screen. All video formats are scaled to fit on the screen in the highest quality using 12-bit digital processing, precision scaling, and gamma correction to produce the best images possible. For use outdoors, an optional Sun Shade (part number 829201) is available for the RMTF-170-3G-TT.

The RMTF-170-3G-TT is a tabletop monitor and the RMTF-170-3G-RM is a rack mounted monitor. Except for the mounting style, these monitors are identical, so for convenience, this manual will generally only refer to them as RMTF-170-3G.

Features

The RMTF-170-3G audio/video monitor is designed for confidence monitoring of two 3G/HD/SD-SDI inputs, one of which has a regenerated output. It also can monitor one HDMI, and one CVBS composite analog video input. The input signals are easily selected and displayed. Two to sixteen audio channels may be selected for visual monitoring on bar graph style level meters. On screen markers, waveform, vector, and histogram displays can be enabled on this full-featured monitor. Focus Assist and Zebra modes can be engaged to assist with camera adjustments. Camera Look Up Tables (LUT) are supported, as well. A single speaker with a left / right mix provides audio monitoring.

Parameters are selected and adjusted using an On Screen Display (OSD) Menu. There are also four function buttons which can immediately enable or disable selected features. These buttons can double as user preset selectors which can call up any of four preprogrammed video setups.

Safety

Instructions

- 1. Read, keep, and follow all of these instructions; heed all warnings.
- 2. Do not use this equipment near water.
- 3. Use only a dry cloth to clean the equipment.
- 4. Do not block any ventilation openings.
- 5. Do not install near any heat source such as a radiator, heat register, amplifier, or



stove.

6. Do not attempt to plug the unit into a two-blade outlet (with only two prongs of equal width).

Important: By design, this monitor will only plug into a three-prong outlet for your safety. If the plug does not fit into the outlet, contact an electrician to replace the obsolete outlet.

- 7. Protect the power cord from being walked on or pinched, particularly at plug connection on the equipment and at the socket.
- 8. Use only the attachments/accessories specified by the manufacturer.
- 9. Unplug the equipment during lightning storms or when unused for long periods of time.
- 10. Refer all servicing to qualified service personnel. Servicing will be required under all of the following conditions:
 - a. The equipment has been damaged in any way, such as when the powersupply cord or plug is damaged.
 - b. Liquid had been spilled or objects have fallen onto the equipment.
 - c. The equipment has been exposed to rain or moisture.
 - d. The equipment does not operate normally.
 - e. The equipment has been dropped.

Safety Symbols



The symbol to the left warns of electric shock hazard inside the unit. Disconnect the power cord before removing access panels when installing upgrades. Only qualified service personnel are to operate the equipment with covers removed, and are to exercise caution to avoid personal injury.

Mounting

The RMTF-170-3G-TT is designed to be placed on a tabletop or other flat surface. Position either unit at ear/eye level for best high frequency response and visual observation of the display screen. Please adhere to the clearances listed in Table 1-1.

The RMTF-170-3G-RM is designed to be mounted in 6RU of a standard 19" rack. It may be tilted forward for easier viewing. Position either unit at ear/eye level for best high frequency response and visual observation of the display screen. Please adhere to the following clearances:



Table 1-1: Recommended Clearances

Clearance	Surface
24″	Front
3″	Rear
2″	Sides
1.75″	Top and Bottom (if near other equipment)
0″	Top and Bottom (if no other equipment)

Heat Dissipation

The ambient temperature near the product should not exceed 40° Celsius (104° Fahrenheit). When rack mounting, adjacent devices can be rack mounted in proximity to the unit if this temperature is not exceeded. Otherwise, allow a 1RU (1.75"/44.45mm) space above and below the unit for air circulation. For table top operation, in warm environments, allow an inch of space above and below the unit for air circulation.

Important

The heat generated by the digital circuitry, power supplies, and other components is vented by slots in the back of the unit. Therefore, as a safety precaution, you must allow proper ventilation on these surfaces.

Sympathetic Vibration

Sympathetic vibration from other equipment (cables, etc.) in the rack may be serious enough to interfere with the unit's sound quality. If you experience sympathetic vibrations, use thin card stock, felt, foam, or weather-stripping between the vibrating surfaces. Tie loose cables securely with cable ties.

Mechanical

The sturdy chassis is very shallow from front to back making it very stable when used with its table stand. It can be tilted forward or backward for viewing, if necessary. The weight of internal components is distributed fairly evenly around the unit.

Electrical Interference

Be careful to avoid mismatched cable types and other similar causes of undesired reflections in digital signal systems. If severe enough, such reflections can result in corruption of the digital data stream. As with any audio equipment, maximum immunity from electrical interference requires the use of shielded cable; however, satisfactory results can sometimes be obtained without it. The internal circuitry ground is connected to the chassis.

Power

The unit connects to the AC mains power source (14W, 100 to 240 VAC, ±10%,



50/60Hz) through the IEC connector provided on the rear panel. Alternately, it can be powered from a camera battery, which installs on the rear panel.

When the mains plug or appliance coupler is used as the disconnect device, the disconnect device should remain operable.

Compliance

FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at their own expense.

ICES-003

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.



CHAPTER 2: Local Operation

The RMTF-170-3G front and rear panels are described in this chapter.

Front Panel





- 1. **Tally Lights**: This tri-color (red/green/amber) light is controlled through a RJ45 connector on the rear panel. For more information about the RJ45 connector, refer to the Rear Panel section of this chapter. When first connected to power, the Tally Light glows amber until the unit is ready for operation.
- 2. **LCD Screen**: The LCD screen displays the audio meters, waveform, vector, or histogram displays, menus, and OSD features superimposed over the video.
- 3. **Power**: The **Power** button turns the LCD screen to On or Standby mode. The adjacent **Power Indicator** glows green to indicate On and red to indicate Standby. To prevent the operator from accidentally switching the monitor to Standby mode, the **Power** button must be held for 2 seconds.
- 4. Input: The Input button selects the video/audio input to be monitored from the



various connectors on the rear panel. The currently selected input source is indicated when the **Input** button is pressed. Repeated presses change the input source.

 F1/U1, F2/U2, F3/U3, F4/U4 Function/User Keys: These keys are dual purpose. Momentarily pressing F1, F2, F3, or F4 will activate the assigned function. The default assignments are as listed in Table 2-1. The action of each Function Key can be selected from a wide variety of actions in the Function Key Menu as described in Table 2-9. Holding U1, U2, U3, or U4 for 2 seconds will instead activate the User Preset associated with the key. Refer to Table 2-9.

Key	Default Action
F1	Scan
F2	Marker
F3	Audio Meters
F4	Blue Only

Table 2-1: Default Function Key Actions

- OK/Menu: Press this button to display the OSD Menu. Refer to the OSD Menus section of this chapter for operation and content of these menus. When the OSD Menu is displayed, pressing this button accepts selections in the menus and sub-menus.
- 7. Down: When the OSD Menu is not being displayed, pressing this button displays the Quick Menu, which cycles through frequently used volume and image controls. Refer to the Quick Menu section of this chapter. When the OSD Menu is displayed, the Down button navigates down through the menu and sub-menu selections and can be used to adjust the settings.
- 8. **Up**: When the OSD Menu is displayed, the **Up** button navigates down through the menu and sub-menu selections and can be used to adjust the settings. It also adjusts the items in the Quick Menu.
- 9. **Left/Exit**: In the OSD Menu, this button backs out of selections. In the Quick Menu, this button reduces the value of any selection.
- 10. **Right/Next**: In the OSD Menu, this button advances into selections, or advances to the next menu page. In the Quick Menu, it increases the value of any selection.

On-Screen Display Features

Functions and parameters can be selected and adjusted using the On Screen Display (OSD) Menu. Refer to the **OSD Menus** section of this chapter.

Overlays can be added by the operator for **Area & Safety Markers**, **Center Marker**, and to display names as **IMD** (**I**n **M**onitor **D**isplay) for identification.

Video effects such as **Monochrome**, **Blue Only**, **Focus Assist**, **False Color Exposure Assist**, and other features can be used to assist setup. For convenience and quicker access, these and other features can be assigned to the **Function Keys**.



Audio level meter displays, for up to sixteen channels, can be displayed on either the left or the right of the display. They can show VU, PPM (PK) or both with assignable -20db or -18db reference levels.

Waveform (Y or Line), **Vectorscope**, or **Histogram** can be shown in various positions almost anywhere on the screen.

The de-embedded **Timecode** from the HD/SD-SDI source displays on the lower part of the screen.



Figure 2-2: Display Features

- 1. **Input Status**: Displays the detected input and video parameters of the signal: vertical active line count, (i)nterlaced or (p)rogressive, and field/frame rate in Hz. This display is controlled be a setting in the Config Menu. Refer to Table 2-9.
- 2. **Area Marker**: Used to mark an alternate aspect ratio area of the image. You can set whether to display it, the brightness, and the matte mode in the Config Menu. Refer to Table 2-9.
- 3. **Safety Marker**: This is used to mark a percentage area, inside of the image, safe for titles to be located. You can set whether to display it, as well as its display mode, in the Config Menu. Refer to Table 2-9.
- 4. **Center marker**: Cross hairs are displayed in the center of the screen, marking the center of the image. You can set whether to display them in the Config Menu. Refer to Table 2-9.
- 5. **IMD**: The IMD Menu provides settings to customize the IMD (In Monitor Display) text area to show a static line of characters, numbers, and certain symbols or to receive dynamic messages to be displayed. Refer to Table 2-10.
- 6. **Audio Level Meters**: Levels for the audio channels are displayed on up to sixteen bar graph meters as left/right pairs. The meters can appear on the left or the right side of the screen. Refer to Table 2-9.



- 7. **Timecode**: The de-embedded timecode from the HD/SD-SDI source displays on the lower part of the screen. The timecode setting is located in the Config Menu. Refer to Table 2-9.
- 8. **Waveform/Vectorscope/Histogram**: These can be displayed only for SDI signals. The waveform and vector of the input signal display are configurable in the Config Menu. Refer to Table 2-9.

Rear Panel



Figure 2-3: Rear Panel Layout

Important:



By design, the supplied AC mains power cord will only plug into a three-prong grounded outlet for your safety. If the plug does not fit into the outlet, contact an electrician to replace the obsolete outlet. The symbol to the left warns of electric shock hazard inside or outside the unit. Disconnect the power cord before removing access panels.

1. **SDI 1 In**: This input connector accepts 3G/HD/SD-SDI video signals. It is



compliant with SMPTE 424M, SMPTE 259M, SMPTE292M/ITU-R BT601. It can be viewed using the **SDI1** selection on the **Input** button menu.

- SDI 1 Out: This connector provides a regenerated duplicate of the SDI 1 In signal. This connection is compliant with SMPTE 424M, SMPTE 259M, SMPTE292M/ITU-R BT601.
- SDI 2 In: This is the second 3G/HD/SD-SDI video signal input. This connection is compliant with SMPTE 424M, SMPTE 259M, SMPTE292M/ITU-R BT601. It can be viewed using the SDI2 selection on the Input button menu.
- 4. **Video In**: This is the input for an analog CVBS video signal. It can be viewed using the **Video** selection on the **Input** button menu.
- 5. **HDMI In**: This input supports HDMI and DVI signals. It uses an HDMI Type-A connector. It can be viewed using the **HDMI** selection on the **Input** button menu.
- 6. **AUD In**: An analog stereo audio input related to the Line 1 video signal is provided on a standard 1/8" stereo jack. This has a $47K\Omega$ input impedance and will accept up to a 5dBu signal. This input is selected when the **Video** selection is made on the **Input** button.
- 7. **USB**: A dual purpose USB connector is provided which can be used to load a camera look up table (LUT). This connector can also be used for software upgrades.
- 8. **Headphone**: A standard 1/8" stereo headphone jack is provided. The speaker will mute when a headphone is inserted into this jack.
- 9. **Audio Out**: A pair of analog outputs is provided on RCA jacks. They will output the audio from the selected video source to be used with external amplifiers and speakers if needed. They have a 500Ω output impedance and will produce up to a 5dBu signal.
- 10. **AC Power Connector**: The supplied IEC cord plugs into this connector. The required power is 100 to 240VAC 50/60Hz.
- 11. **DC Power Connector**: A standard XLR-4F connector can plug into this XLR-4M connector to supply 11 to 17VDC at 3A to the product as an alternative to AC power.
- 12. **Battery Holder**: An optional 11.0 to 16.8 V camera battery can be mounted to the rear panel for portable use in the field.
- 13. **Power Switch**: This switch removes all power from the product. Normally, since this switch is on the rear panel, it is left in the **1 (On)** position and the front panel **Power** button is used to start and stop product operation.
- 14. **RS-485 In/Out**: These RJ-45 jacks are used for dynamic Tally/IMD controls. Two jacks are provided for in & out daisy chain arrangements. They are wired identically. Refer to Figure 2-4 below for the pinout and to Table 2-2 for terminal connections. Either CAT5 or CAT6 cables may be used for these jacks.
- 15. **Speaker**: The audio monitoring speaker is positioned on the rear panel. The volume of the speaker is controlled using the Quick Menu. Refer to the Quick Menu section of this chapter.



Rear Panel Connectors

The following figure and table detail the connections of the RS-485 connectors on the rear panel. The tables are also silkscreened on the rear panel of the unit for your convenience.





Table 2-2: RS-485 I/O Connections

Pin	RS-485 Terminal Name
1, 2	GND
3	Tx- (pair A)
4	Rx+ (pair B)
5	Rx- (pair B)
6	Tx+ (pair A)
7, 8	NC

Front Panel Menu Operation

In the following descriptions, refer to Figure 2-5 for the location of each control button.

Figure 2-5: Screen Control Buttons



Input

The Input button lets you select between available inputs for viewing. Press the Input button repeatedly to switch between the connected inputs: **SDI1**, **SDI2**, **VIDEO**, and **HDMI**.



Quick Menu

The Quick Menu provides quick access to a few commonly used features, as listed in Table 2-3. The Quick Menu appears as shown in Figure 2-6.

Figure 2-6: Quick Menu - Volume Setting



The following is a description of how to use the Quick Menu:

- 1. Press the **Down** button to display the Quick Menu and select through the items that can be adjusted, as listed in Table 2-3.
- 2. Use the **Left** and **Right** buttons to change the value for the item displayed.
- 3. Press the **Down** button again to display the next adjustable item.
- 4. The Quick Menu will time out with no button presses. Alternatively, you may press the **OK** button for the menu to disappear.

Parameters	Default Value	Domain Range
VOLUME	16	0 - 31
BRIGHTNESS	50	0 - 100
CONTRAST	50	0 - 100
SATURATION	50	0 - 100
BACKLIGHT	5	0 - 10
SHARPNESS	8	0 - 63

Table 2-3: Quick Menu

OSD Menus

The OSD Menus allow you to adjust a wide variety of control parameters for the monitor. Refer to Table 2-4 through Table 2-11 for typical values and domain ranges. The following is a description of how to use the OSD Menus:

- 1. Press the **OK/Menu** button to display the Main Menu.
- 2. Use the **Up** and **Down** buttons to navigate through the menus.
- 3. Press the **OK** button to enter the parameter selections in the chosen submenu.
- 4. Use the **Up** or **Down** buttons to cycle through the submenu selections.
- 5. When the desired option is highlighted, press the **OK** button to select it.
- 6. Use the **Up** or **Down** buttons to adjust the parameter value up or down, make a selection, or turn a function on or off.
- 7. Press the **OK** button to accept your parameter change -or- press the **Left** button to cancel your change.



8. Press the **Left** button to back out of any submenu, and finally to remove the OSD Menus from the screen.

OSD Menus

The following tables describe the information and settings available in the OSD Menu system. Use the instructions in the previous section to navigate the menus.

Status Display			
Parameters	Default Value	Domain Range	Description
INPUT	SDI-1	SDI-1, SDI-2, Video, HDMI	
SIGNAL FORMAT	4:2:2 YCbCr 10	Refer to Table 3.2	
COLOR RANGE		64 - 940	
YCbCr COLOR MATRIX	ITU-R BT.709		
GAMMA	2.2		
COLOR TEMP	D65	D32, D93, D65, D56, D50	Display only, for the value
COLOR SPACE	P3		of the parameter.
CAMERA LUT TYPE	CAMERA SDR		
USER PRESET	USER1	USER1 - USER4	
Menu Page 2			
MODEL	RMTF-170-3G		
SERIAL NUMBER	-		
FIRMWARE VERSION	-		

Table 2-4: Status Display Menu Structure



Input Config				
Parameters	Default Value	Domain Range	Description	
SDI IN1	ON	OFF, ON	Enables or disables	
SDI IN2	ON	OFF, ON	the input choices	
VIDEO	ON	OFF, ON	available in the	
HDMI	ON	OFF, ON	Input Select Menu	
NTSC PHASE	0	-50 to 50	Only for NTSC signal format	
SIGNAL FORMAT	AUTO	Refer to Table 3.2	Input signal format	
COLOR RANGE	64 - 940	64 - 940 64 - 1023 0 - 1023	Set color range.	
YCbCr COLOR MATRIX	AUTO	AUTO ITU-R BT.709 ITU-R BT.2020	Set YCbCr color matrix	

Table 2-6: Color Management Menu Structure

Color Management			
Parameters	Default Value	Domain Range	Description
GAMMA	2.2	1.8, 2.2, 2.4, 2.6, 2.8, bt.1886, PQ, HLG	Adjust Gamma.
COLOR TEMP	D65	D93, D65, D61, D55, DCI, USER1, USER2	Set the color temperature.
RED GAIN			Set the gain for each color.
GREEN GAIN	512	0 to 512	
BLUE GAIN			
COPY FROM	D93	D93, D65, D61, D55, DCI	Copies this set of color parameters to USER.
RESET	Resets Gain and Offset to Factory Default		
COLOR SPACE	EBU NATIVE SMPTE-C EBU Select the co ITU-709 ITU2020 P3		Select the color matrix.
Menu Page 2			
CAMERA LUT	ON	ON, OFF	Enable or disable camera LUT.



CAMERA LUT TYPE	CAMERA SDR	CAMERA SDR CAMERA HDR USER	Set a LUT from the corresponding list.
CAMERA SDR	2.2	Refer to Table 2-8	Load the selected SDR LUT.
CAMERA HDR		Refer to Table 2-8	Load the selected HDR LUT.
USER	USER1	USER1 - USER16	Load a custom LUT file.
LOAD LUT FILE	Use these steps to load a LUT file from a USB Flash Drive 1. Insert the Flash Drive and select LOAD LUT FILE. 2. Select USER. 3. Select the desired file from the Flash Drive. 4. Choose User1 - User16 as a storage location. 5. Press OK/Menu. 6. Turn off the Power button, wait 15 seconds and turn it on again. 7. In this menu, set Camera LUT Type to USER. 8. Set USER to the storage location you chose in step 4.		

Table 2-7: Supported Camera LUTs

Camera LUT	Look Up Table (LUT) Name	Company
SDR	ARRI_LogC_Rec709	ARRI
	BMD_4KFilm_Rec709	
	BMD_4KFilmV2_Rec709	
	BMD_4KFilmV3_Rec709	Blackmagic
	BMD_CCFilm_Rec709	
	BMD_CCFilmV2_Rec709	
	Canon_CLog1Cine_Rec709_FF_V1.1	
	Canon_CLog2Cine_Rec709_FF_V1.1	Canon
	Canon_CLog3Cine_Rec709_FF_V1.1	
	DJI_Phantom3DLog_Rec709_Improv	
	DJI_Phantom4DLog_Rec709	זוס
	DJI_Phantom4DLog_Rec709_Improv	
	DJI_X5DLog_Rec709_Improv	
	FUJI_FLogFGamut_FLogRec709_V1	Fujifilm
	FUJI_FLogFGamut_WDRRec709_V1	i ujinin
	GoPro_Protune_Rec709	GoPro
	JVC_JLog1_Rec709_Daylight	IVC
	JVC_JLog1_Rec709_Tungsten	
	Panasonic_VLog_V709_V1	Panasonic
	RED_L3G10RWG_Rec709_R1_V1.13	RED



		_		
	RED_L3G10RWG_Rec709_R2_V1.13			
	RED_L3G10RWG_Rec709_R3_V1.13			
	RED_L3G10RWG_Rec709_R4_V1.13			
	Sony_SLog2SGamut_LCRec709			
	Sony_SLog2SGamut_LCRec709A	Sony		
	Sony_SLog3SG3Cine_LCRec709			
	Sony_SLog3SG3Cine_LCRec709A			
	ARRI_LogC_HLG_Rec2020			
	ARRI_LogC_PQ_Rec2020			
	Canon_Clog2Cin_HLG_Rec2020			
	Canon_Clog2Cin_PQ_Rec2020			
	Canon_Clog3Cin_HLG_Rec2020			
	Canon_Clog3Cin_PQ_Rec2020			
нов	Panasonic_VLog_HLD_Rec2020	OSEE		
TIDI	Panasonic_VLog_PQ_Rec2020	USEL		
	RED_L3G10_HLG_Rec2020			
	RED_L3G10_PQ_Rec2020			
	Sony_SLog3_Cin_HLG_Rec2020			
	Sony_SLog3_Cin_PQ_Rec2020			
	Sony_SLog3_SG3_HLG_Rec2020			
	Sony_SLog3_SG3_PQ_Rec2020			

Table 2-8: Gamma Range vs Camera LUT

Camera LUT	Gamma Range
CAMERA SDR	1.8, 2.2, 2.4, 2.6, 2.8 BT.1886
CAMERA HDR	PQ, HLG
USER or OFF	1.8, 2.2, 2.4, 2.6, 2.8 BT.1886, PQ, HLG



User Config				
Parameters	Default Value	Domain Range	Description	
USER PRESET	USER1	USER1 USER2 USER3 USER4	Apply the current User Configuration settings to one of the four possible Presets.	
F1	SCAN	CAMERA LUT BLUE ONLY MONO MARKER	Set up the F1/U1 Function key action.	
F2	MARKER	AUDIO METERS TIME CODE WAVEFORM TYPE VECTORSCOPE HISTOGRAM	Set up the F2/U2 Function key action.	
F3	AUDIO METERS	SCAN ASPECT NATIVE MUTE IMD DISPLAY	Set up the F3/U3 Function key action.	
F4	BLUE ONLY	FALSE COLOR FOCUS ASSIST PEAK ZEBRA UNDEF (no function)	Set up the F4/U4 Function key action.	
Menu Page 2				
AUDIO SOURCE	EBD	EXT: Analog Inputs EBD: Embedded Signal OFF: No audio	Select the audio source among the available signals.	
SPEAKER L	EMB CH1	For an SDI EBD Source: CH1 to CH16	Select the input channel for the speaker and left headphone.	
SPEAKER R	EMB CH2	For a VIDEO Source: CH1, CH2 For an HDMI EBD Source: CH1, CH2	Select the input channel for the speaker and right headphone.	
METER DISPLAY	OFF	ON, OFF	Set whether to display the audio meters.	
METER SELECT	CH1-2	CH1-2, G1, G2, G3, G4, G1+G2, G1+G3, G1+G4, G2+G3, G2+G4, G3+G4, G1- G4	Select channels or SDI groups to display on the meters.	
METER POSITION	LEFT	LEFT RIGHT	Select the displayed position of the audio meters.	



		MODE1: meters only	
DISPLAY MODE	MODE1	MODE2: meters with channel numbers and frame	Select the appearance of the meters.
METER OPACITY	0	0 = 100% 1 = 50%	Set the opacity of the audio meters.
Menu Page 3			
MARKER	OFF	OFF, ON	Enable or disable the display of the markers that have been set up in this menu.
ASPECT MARKER	OFF	16:9 4:3 15:9 14:9 13:9 1.85:1 2.35:1 Variable Off	Select the aspect marker according to the display aspect ratio.
VARIABLE ASPECT	3.00	1.00 - 3.00 in 0.01 steps	When the Aspect Marker is set to Variable, use this ratio.
CENTER MARKER	OFF	OFF, ON	Turn center marker display on or off.
SAFE AREA MARKER	OFF	OFF 80% 85% 88% 90% 93% 95%	Set safety marker size according to the aspect ratio and scan mode.
MARKER FIT	OFF	OFF: Safe Area Marker is based upon the current input source ON: Safe Area Marker is based upon the image within the current aspect	Select Safe Area Marker setup.
MARKER LEVEL	1	1: 50% 2: 75% 3: 100%	Set the luminance of all of the markers.
MARKER MAT	OFF	OFF, HALF (<i>Background</i> <i>50%)</i> BLACK (Refer to Figure 2-7)	Set the transparency of the area marker mat.
CROSSHATCH	ON	OFF, ON	Set whether to show the crosshatch.



Menu Page 4				
WFM FORM TYPE	OFF	WAVEFORM VECTOR WF, WIDE HDR WFM OFF	Set the type of waveform / vector display.	
WAVEFORM SIZE	SMALL	SMALL MEDIUM LARGE	Set the size of the waveform display.	
WAVEFORM LOCATION	TOP RIGHT	<u>SMALL</u> : LEFT UP, CENTER UP, RIGHT UP, RIGHT CENTER, RIGHT DOWN, CENTER DOWN,LEFT DOWN, LEFT CENTER <u>MIDDLE</u> : RIGHT DOWN, CENTER	Set the displayed position for the waveform display according to Waveform Size	
		DOWN, LEFT DOWN LARGE: CENTER DOWN		
VECTOR- SCOPE	OFF	OFF, ON	Enable or disable vectorscope display.	
VECTOR- SCOPE LOCATION	TOP RIGHT	LEFT UP, CENTER UP, RIGHT UP, RIGHT CENTER, RIGHT DOWN, CENTER DOWN, LEFT DOWN, LEFT CENTER	Set Vectorscope location.	
HISTOGRAM	OFF	OFF LUMA RGB	Enable or Disable histogram display and set histogram mode.	
HISTOGRAM LOCATION	TOP RIGHT	LEFT UP, CENTER UP, RIGHT UP, RIGHT CENTER, RIGHT DOWN, CENTER DOWN, LEFT DOWN, LEFT CENTER	Set Histogram location.	
OPACITY	0	0 = 100% (opaque) 1 = 75% 2 = 50% 3 = 25%	Set the trans-parency of Waveform, Vectorscope, and Histogram	



Menu Page 5				
		OFF: Normal Video		
FOCUS ASSIST	STANDARD	GRAY: Image is in gray mode and displays edge of images with color selected in Focus Color.	Enable or Disable Focus Assist and set mode. When Focus Level valu is exceeded, the edge detected will be in the	
		COLOR: Displays edge of images with color selected in Focus Color.	Focus Color.	
FOCUS ASSIST COLOR	RED	RED GREEN BLUE	Set the color for the detected edge of images.	
FOCUS ASSIST LEVEL	50	0 - 100	Set the edge difference value in image. Larger value means more detail detection.	
PEAK	OFF	OFF, ON	Enable or Disable Peak function. Over sharpen the image.	
PEAK LEVEL	1	1 - 8	Set the sharpness level. Higher value gives a sharper image.	
FALSE COLOR	OFF	OFF, ON	Enable or Disable False Color Exposure Assist function.	
FALSE COLOR TYPE	SPECTRUM	Spectrum SONY Slog3 SONY Slog2 ARRI LogC Canon Clog2 Canon Clog3 Panasonic Vlog RED RedLogFilm RED RL3G10 BMD BMD 4K ARRI Rec709 SONY LC709A SONY LC709 RED G3 RED G4	Set the type of False Color Exposure Assist Display.	
ZEBRA	OFF	OFF, ON	Enables or Disables the Zebra function, comparing luminance with the Zebra Level, and displays zebra pattern wherever luminance is higher.	

Page 22



ZEBRA LEVEL	50	0 - 100	Set the reference level for detecting luminance.	
Menu Page 6				
INTERNAL SIGNAL	OFF	OFF, ON	Enable or Disable the internal color bar signal display.	
OSD TIME	ON	ON, 10S, 30S, 60S	Set the display timeout of the OSD Menu.	
TIMECODE	OFF	OFF, ON	Enable or Disable the Timecode display.	
STATUS DISPLAY	OFF	OFF, ON, AUTO	Set the timeout of the Status Information display.	
LANGUAGE	ENGLISH	ENGLISH CHINESE	Set product language.	
MONITOR RESET	Use this selection with caution to reset the product settings to the way they were when it left the factory. IF YOU ARE UNSURE OF WHETHER TO PERFORM A FACTORY RESET, CLICK CANCEL AND THEN CONTACT WOHLER TECNICAL SERVICE FOR ADVICE.			
UPGRADE FIRMWARE	Use this selection to upgrade the firmware. Follow the directions on the screen.			

Figure 2-7: Marker Mat Effect



Marker Mat = OFF



Marker Mat = HALF



Marker Mat = BLACK



IMD Menu				
Parameters	Default Value	Domain Range	Description	
IMD DISPLAY	ON	ON, OFF	Set whether to enable the IMD.	
IMD PROTOCOL	LOCAL	TSL3.1 TSL4.0 LOCAL	Select an IMD protocol.	
IMD CHARACTER	RMTF-170-3G	(Up to 16 characters of text for static LOCAL display)	Set the IMD message.*	
IMD COLOR	RED	RED, GREEN, YELLOW	Set the color of the IMD characters.	
MONITOR ID	0	0 - 255	Set the ID number for each monitor	
BAUD RATE	115200	2400, 4800, 9600, 19200, 38400, 57600, 115200	Set the BAUD rate for RS-485 communication.	

* **To enter the characters** for the IMD CHARACTER setting, navigate to the setting and press **Next**. Press **Up** or **Down** repeatedly to locate the first character and press **Next** to move to the next character. Press **Up** or **Down** again repeatedly to locate the second character and press **Next**. Repeat this process until all of the characters (up to 16) have been entered. Then press **OK/Menu** to exit.

Table 2-11: Key Inhibit Menu Structure

Key Inhibit					
Parameters Default Value Domain Range Description					
KEY INHIBIT	OFF	OFF, ON	Enable or Disable operator access to front panel keys.		



CHAPTER 3: Technical Info

Specification	Values/Domains	
AC Power Requirements	100 V to 240 VAC ± 10%, 50/60Hz	
AC Power Consumption	14 Watts	
DC Power Requirements	11 - 17 VDC @ 3A	
Dimensions	16.6″ H x 10.4″ W x 1.9″ D 422 mm H x 264 mm W x 49 mm D	
Weight	6.6 lbs. (3 kg)	
Supplied Accessories	AC Power Cord	
Display Type	IPS-LCD with LED Backlight	
Number of Displays	1	
Screen Size	17.3" diagonal per screen	
Screen Resolution	1920(H) x 1080(V)	
Aspect ratio	16:9, 4:3	
Display Area (mm)	382(H) x 215(V)	
Viewing Angle	178°(H) x 178° (V)	
Color Depth	16.7m colors	
Contrast Ratio	800:1	
Brightness	300 cd/m ² , typical	
Backlight	White LED	
Response Time	14 ms	
	Video: PAL/NTSC	
	SD-SDI: SMPTE 259M, ITU-R BT.656	
Video Inputs	HD-SDI: SMPTE 292M/274M/296M	
	3G-SDI: SMPTE 425-Level A	
	HDMI: 1.3a	
Video Input Impedance	SDI and CVBS: 75Ω	
Audio Inputs	1 Stereo Pair; Analog 1/8" jack	
Audio Input Impedance	20kΩ	
Audio Outputs	1 Selected Pair; 1/8" Stereo Headphone jack	
Speaker	5W (Mono)	
Dynamic Tally/IMD	RS-485; TSL on RJ-45	
LUT / Software Update	USB	

Table 3–1: Specifications





Figure 3–1: RMTF-170-3G Series Block Diagram

Supported Video Formats

The RMTF-170-3G monitor will display the video formats listed on the following page in Table 3-2.



Format	Signal Format	SDI	Video	HDMI
480i60			Х	
576i50			Х	
720p24/23.98		Х		
720p25		Х		
720p30/29.97		Х		
720p50		Х		Х
720p60/59.94		Х		Х
1080sf24/23.98		Х		Х
1080sf25	4:2:2 YCbCr 10 bit	Х		Х
1080sf29.97		Х		Х
1080sf30		Х		
1035i60/59.94		Х		
1080i50		Х		Х
1080i60/59.94		Х		Х
1080p24/23.98				Х
1080p25		Х		Х
1080p30/29.97		Х		Х
1080i50	4:2:2 YCbCr 12 bit	Х		
1080i60/59.94	4:4:4 YCbCr 10 bit 4:4:4 YCbCr 12 bit 4:4:4 RGB 10 bit 4:4:4 RGB 12 bit	Х		
1080p24/23.98		Х		
1080p25		Х		
1080n30/20 07	4:4:4 XYZ 10 bit	V		
1000000/20.07	4:4:4_XYZ_12 bit	X		
1080p50		Х		
1080p60/59.94	4.4.4 TODET 10 DIE	Х		
1080sf24/23.98		Х		
1080sf25	4:2:2 YCDCr 12 Dit 4:4:4 YChCr 10 hit	Х		
1080sf29.97	4:4:4 YCbCr 12 bit	Х		
1080sf30	4:4:4 RGB 10 bit 4:4:4 RGB 12 bit	Х		
1080p24/23.98		Х		
1080p25	4:4:4_XYZ_10 bit	Х		
1080p30/29.97	4:4:4_XYZ_12 bit	Х		
1080p48/47.95		Х		
1080p50	4:4:4 YCbCr 10 bit	Х		
1080p60/59/94		Х		



Page _

